



- CR ELECTRONIC OVEN CONTROL UNIT
- E1 UPPER HEATING ELEMENT
- F1 CIRCULAR HEATING ELEMENT
- H1 LOWER HEATING ELEMENT
- L1 OVEN LAMP
- K2 LED OVEN LAMP
- M1 CAVITY FAN
- M2 DUAL SPEED COOLING FAN
- M3 TURNSPIT MOTOR
- MB DOOR LOCK MOTOR
- S1 ELECTRONIC SENSOR
- SW/B DOOR LOCK SWITCH
- SW/P DOOR SWITCH
- SW/EL POWER SUPPLY ELEMENT SWITCH
- SW/F1 AUXILIARY SWITCH
- Y1 THERMOLIMITER
- Y3 THERMOLIMITER
- W MAIN TERMINAL BLOCK
- X9 EARTH UPPER HEATING ELEMENT

- 00 BLACK
- 11 BROWN
- 22 RED
- 33 ORANGE
- 44 YELLOW
- 55 GREEN
- 66 BLUE
- 77 VIOLET
- 99 WHITE
- 09 WHITE-BLACK
- 29 WHITE-RED
- 49 WHITE-YELLOW
- 69 WHITE-BLUE
- 90 GREY
- 92 PINK
- 45 YELLOW-GREEN

4000 106 77631